**INSTRUCTIONS: TECPINT AIR DEPUR ECO-TERMIC**

**CHECK THE CONDITION OF THE SURFACE:**

- If the surface is in poor condition or has poorly adhered or highly porous paint residues, remove any loose material and apply our **TECPINT SILICATE CONSOLIDATOR** product pure and undiluted. Allow a minimum drying time of 10 hours before applying the paint. For unpainted plaster or plasterboard surfaces, use **TECPINT PRIMER** or **TECPINT PRIMER GEL**.

TECPINT SILICATE CONSOLIDATOR
TECPINT PRIMER

---

**APPLICATION OF TECPINT AIR DEPUR ECO-TERMIC**

Due to its natural composition, this product behaves differently from conventional plastic paints. It is supplied with a thicker consistency, which is completely normal for this type of natural mineral paint. As a natural product, it tends to thicken once packaged.

**Instructions for use:**

1. In the original container, mix the product thoroughly for 3–4 minutes using an electric mixer or, alternatively, a non-circular stick, until it reaches a consistency similar to standard emulsion paint.
2. Pour the amount needed into a bucket and, if necessary, add approximately 5% water. Stir well until the desired texture is achieved.

- For interior applications, use a **drip-resistant roller** (for exterior applications, a **wool or long-pile roller** is recommended). To achieve the best thermal performance, three coats are recommended, allowing a minimum drying time of 10 hours between coats.

TECPINT AIRDEPUR ECOTERMIC

If you require further technical assistance, please contact us on +34 962 117 117, via WhatsApp through www.tecnoprodist.com, or by email at info@tecnoprodist.com

Kind regards,
Technical Department
Tecno Prodist